


# Evidence Presentation Unit Instructions



1. Turn **ON** System Power  
(button on Judges' bench)



2. Press **Power** Button for EPS

3. CD/DVD/VCR Player(s)

4. Tape Deck

5. Remote storage drawer

1. Press **System Power** button on Judge Bench (*in Up position*)

2. Press **Power** Button for EPS

3. CD/DVD player opens with Toshiba Remote

4. Tape deck opens by pressing Open

5. Remote control storage drawer

6. PC in lower left of unit (recommend using PC DVD player) (*return wireless mouse to charger*)  
(*Your DVD/Audios must have Microsoft Media Player codec pack to play in PC*)

`media.player.codec.pack.v4.2.2.setup.exe`  
(*PC goes into sleep mode; Press Blue power button to resume*)

Computer

USB Data Ports



# Evidence Presentation Unit Instructions


8. **PC** is on when displaying this screen  
type password & enter to log on




9. **Elmo** Document Camera (*located on left side of unit*)  
for document/photo display  
**turn power on** located on side.





Click **Elmo** Icon



on desktop



Click **Capture** tab - Click **full screen** Icon



10. **Laptop use** - plug laptop into **KVM** Switch on top of unit (as needed)

**KVM Cable**  
for laptop



Plug **green** audio cable in laptop for sound.

**Press KVM Button**

to switch from PC to AV (audio visual to use Elmo)